Northville Holtsville, NY.
Shell Terminal ID: Y745
Shell Loading

Effective 05/01/2017

Rack Customer Pick Up

⬇ Kiosk 1 Pre-Loading
➢ Enter driver # (from loading card)
➢ Enter pin #
➢ Enter Customer Access # (should begin with 140)
➢ Enter Shell Order Number 00

⬇ At Loading Bay
➢ Insert Loading Card
➢ Enter driver pin #
➢ OK To Load
Once authorized to load, proceed as usual

⬇ EXIT BOL Printer
➢ Insert Loading Card
➢ Check BOL for Accuracy
➢ Exit terminal

NOTE: FOR ANY AUTHORIZATION PROBLEMS CALL THE LOADING
SUPPORT SERVICE HELPDESK AT 800-345-6666.

Please use a safe phone/location as Specified in your Driver Training Instructions.