

# Flint Hills Resources Junction City, WI.

Shell Terminal ID: **Y141**

## Shell Loading

Effective 07/01/2014

### Rack Customer Pick Up

- Insert Loading Card
  - Enter driver #
  - Enter FHR Destination #
  - Next you will see a message “Authorizing” or “Wait”
- Once authorized to load, proceed as usual

**NOTE:** FOR ANY AUTHORIZATION PROBLEMS CALL THE LOADING SUPPORT SERVICE HELPDESK AT 800-345-6666.

Please use a safe phone/location as Specified in your Driver Training Instructions.



**Loading Instructions on your Smart Device**