

Petroleum Products Dupont, PA.

Shell Terminal ID: Y419

Shell Loading

Effective 08/01/2017

Rack Customer Pick Up

- Enter Driver pin number at gate which allows gate entry
- Pull under rack hoop up grounding system then loading arms
- Enter truck number
- Enter 5 – digit customer pin number -
- Choose Supplier: (PICK **SOPUS**)
- Select Destination from pick list -
- Choose product and proper loading arm
- Preset gallons – when compartment is done press complete. When all compartments are done. Press print.
- Unhook loading arms
- Unhook grounding system
- Move truck from under rack and go into office for Bol.

Once authorized to load, proceed as usual

NOTE: FOR ANY AUTHORIZATION PROBLEMS CALL THE LOADING SUPPORT SERVICE HELPDESK AT 800-345-6666.

Please use a safe phone/location as Specified in your Driver Training Instructions.