

Sunoco Westville (Eagle Point), NJ.

Shell Terminal ID: Y740

Shell Loading

Effective 05/01/2017

Rack Customer Pick Up

- Insert Loading Card
- Enter driver pin #
- Enter trailer #
- Select Customer Pickup
- Select Supplier or enter Supplier # **450 (Sunoco LLC)**
- Select Customer or enter Customer # **70 (Sunoco Exchange Stock Xfer)**
- Select Account or enter Account # **First 7 Digits of Sunoco DUNS**
- The next prompt will be "Third Party Order #" ... Enter a (0) zero
- Next you will see a message "Please wait for authorization"
Once authorized to load, proceed as usual
- Must use Shell lanes 2 and 3.

NOTE: FOR ANY AUTHORIZATION PROBLEMS CALL THE LOADING SUPPORT SERVICE HELPDESK AT 800-345-6666.

Please use a safe phone/location as Specified in your Driver Training Instructions.